




Wall Mount Instructions For The Razor Crest – (75331)



Right facing

Left facing



Wall Mount Instructions For The Razor Crest – (75331)

on the wall mount, Follow these steps.


Unclip both landing gear surrounds and release the legs by removing the technic axles as shown




Replace the surround and place the 3x4 tile as shown.




Remove the front landing gear foot and remove all top panels as shown.



Wall Mount Instructions For The Razor Crest – (75331)



When handling the Lego set be sure to follow the guidance in the official instruction guide



Using parts from the original display section, create the adaptor part for the minifigure display stand

